

ASSEMBLY INSTRUCTION

MODEL : IFU - AF 5088 DOUBLE BED - Wooden Slat - 6 Support Legs

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

STEP 1

(A) M6 X 100MM JCBC SCREW - 4 PCS
(C) WOOD DOWEL M10 X 40MM - 8 PCS
(D) BARREL NUTS M6 X 15MM - 4 PCS
(F) M4 ALLEN KEY (BALL TYPE) - 1 PC

STEP 2

(A) M6 X 100MM JCBC SCREW - 4 PCS
(C) WOOD DOWEL M10 X 40MM - 8 PCS
(D) BARREL NUTS M6 X 15MM - 4 PCS
(F) M4 ALLEN KEY (BALL TYPE) - 1 PC

STEP 3

(A) M6 X 100MM JCBC SCREW - 8 PCS
(C) WOOD DOWEL M10 X 40MM - 4 PCS
(D) BARREL NUTS M6 X 15MM - 8 PCS
(F) M4 ALLEN KEY (BALL TYPE) - 1 PC

STEP 4

(B) M6 X 35MM JCBC SCREW - 6 PCS
(F) M4 ALLEN KEY (BALL TYPE) - 1 PC

ASSEMBLY INSTRUCTION

MODEL : IFU - AF 5088 DOUBLE BED - Wooden Slat - 6 Support Legs

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

STEP 5

REQUIRED ASSEMBLY TOOLS :
POZI SCREWDRIVER - 1PC

(E) M4 X 32MM CSK SCREW - 24 PCS

REMARK : ATTACH PART 8 USING (E) SCREW AND POZI SCREWDRIVER AS SHOWN.

PART LIST		

HARDWARE LIST	

FULL SETUP