




General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.

Notes


- The product is intended for indoor use only. The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- Avoid long-term exposure to humid environments to prevent mildew.
- Keep the product away from fire sources and high temperatures. Do not expose the product to direct sunlight.
- Do not place any hot objects on the surface of the product.
- If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage.
- Please do not stand or sit on the wooden boards.
- Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- Please match the corresponding part and fitting based on the part number in the manual.
- If the part does not match with the fitting, please check the piece as specified in this manual.
- During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- If you accidentally spill water or another liquid on the surface, immediately wipe clean with a dry towel.
- Please keep the product away from sharp, pointed objects and corrosive substances to prevent product damage.
- Please place this item on level, solid ground during use.


Warnings














- Children are not allowed to assemble the product. During assembly, keep all small parts out of the reach of children as they may be fatal if swallowed or inhaled.
- Children are forbidden to climb or play on the product to avoid serious bodily injury caused by the toppling.
- Keep plastic packing bags out of reach of children to avoid any potential danger, such as suffocation.







- Place the product in a suitable environment and use the correct operating voltage.
- Only use the provided adapter. Using a different adapter can cause voltage surges, permanently damaging the switch and light.
- If you notice abnormal heating in the switch or other components, immediately disconnect and stop using the device. Contact us for component replacement.
- If you experience abnormal lighting or flickering, stop using the device and contact us for a replacement.
- Do not modify the system's leads without proper authorization.








					
① X 1	② X 1	③ X 1	④ X 1	⑤ X 2	⑥ X 6
					
⑦ X 1	⑧ X 1	⑨ X 3	⑩ X 3	⑪ X 3	⑫ X 3
					
⑬ X 3					

STEP 1






STEP 2




11




STEP 3






STEP 4




STEP 5



STEP 6






STEP 7





I	X4
	
ø15*3	


STEP 8







STEP 9





F	X12
	
Ø3.5*14	

H	X3
	




STEP 10






STEP 11






STEP 12




STEP 13






STEP 14




STEP 15



STEP 16



STEP 17



RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW INSTRUCTIONS BELOW:

- If you have purchased the item and have simply changed your mind, follow the retailer's instructions for returns.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest that you refuse the delivery. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
- In all circumstances, please save all packaging material and paperwork for the order.
- Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the retailer, you jeopardize your chances of making a claim, and you may not receive a credit for the return.