



ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606



PARTS IDENTIFICATIONS / IDENTIFICATION DES PIECES






ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




(1)	1pc	(6)	1pc	(11)	1pc	(16)	1pc	(21)	3pcs
(2)	1pc	(7)	1pc	(12)	1pc	(17)	1pc	(22)	3pcs
(3)	1pc	(8)	1pc	(13)	2pcs	(18)	1pc	(23)	1pc
(4)	2pcs	(9)	1pc	(14)	1pc	(19)	3pcs		
(5)	1pc	(10)	1pc	(15)	2pcs	(20)	3pcs		

HARDWARE IDENTIFICATIONS/ IDENTIFICATION DU KIT D'ASSEMBLAGE

ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606


A		L29	34pcs
B		Ø15	34pcs
C		Ø22	4pcs
D		Ø8x25	17pcs
E		Ø4x35	6pcs
F		Ø4x25	4pcs
G		Ø7x48	4pcs
H		Ø8xØ16x2	4pcs
I		Ø16	6pcs
J			34pcs
K		Ø4x30	12pcs
L		L20	12pcs
M		Ø12	12pcs
N		Glue: For securing please apply to wood dowel first before inserting into panel	1pc

ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




STEP1/ ETAPE 1

STEP2/ ETAPE 2




ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




STEP3/ ETAPE 3

STEP4/ ETAPE 4




ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




STEP5/ ETAPE 5

STEP6/ ETAPE 6




ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




STEP7/ ETAPE 7

STEP8/ ETAPE 8




ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




STEP9/ ETAPE 9

STEP10/ ETAPE 10




ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




STEP11/ ETAPE 11

STEP12/ ETAPE 12




ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




STEP13/ ETAPE 13

STEP14/ ETAPE 14




ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




STEP15/ ETAPE 15

STEP16/ ETAPE 16




ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606




STEP17/ ETAPE 17

STEP18/ ETAPE 18




ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606





STEP19/ ETAPE 19

STEP20/ ETAPE 20



ITEM NO/NO ARTICLE: TV STAND/Meuble TV/
192605 192606



STEP21/ ETAPE 21

STEP22/ ETAPE 22

