


# ASSEMBLY INSTRUCTIONS

ITEM#: OF4201

## Important Safety Instructions:


- Please read all instructions before beginning assembly
- Please make sure receive all the parcels to start the assembly
- For your safety and convenience, assembly by two people is recommended
- Use the parts and hardware lists to identify and separate each of the components included
- Save all packing materials until assembly is completed to avoid the accidental discarding of smaller parts or hardware




THANK YOU FOR PURCHASING

# PARTS LIST

1 X1	2 X1	3 X1	4 X1	5 X1
6 X2	7 X2	8 X2	9 X4	10 X2
11 X2	12 X1			
















## Maximum weight capacities
















**MAXIMUM WEIGHT:**  
150 LBS (68 KG)


**MAXIMUM WEIGHT:**  
35 LBS (16 KG)

# HARDWARE LIST

Name	Part	Qty.	Spare
A		6	1
B		6	1
C		10	1
D		2	
E	 14"	4	
F		2	
G	 7/8" Screw	4	1
H	 3/4" Nail	16	1
I		2	
J		2	
K	 2" Screw	12	1
L	 1-1/2" Screw	8	1
M	 9/16" Screw	8	1

Name	Part	Qty.	Spare
N	 1/2" Screw	38	4
O		18	2
P		4	
Q		2	
R	 5/6" nail	8	2
S		4	
T		4	
U		1	
DD		4	
U1		4	
U3		4	
U4		2	
U5		2	

Slides Must Be Separated Before Assembly.  
After Separated, Set Aside Until Needed for Assembly.




## STEP 1

**F** x 2pcs 

**G** x 4pcs 

**DD** x 4pcs 


**M** x 8pcs 





x2

## STEP 2


(N) x 12pcs 

(E) x 4pcs   
14" Slide Runner





## STEP 3

(N) x 8pcs 



## STEP 4


**L** x 8pcs





x 2

## STEP 5

**N** x 6pcs




**I** x 2pcs



x 2

## STEP 6


**J** x 2pcs




**D** x 2pcs



**T** x 4pcs






**x 2**



## STEP 7


**K** x 8pcs



# STEP 8







**A** x 6pcs 

**E** x 4pcs



**C** x 10pcs 





**N** x 12pcs 







## STEP 9

**B** x 2pcs







## STEP 10

**K** x 4pcs







## STEP 11

**B** x 4pcs




## STEP 12

**H** x 16pcs




## STEP 13




**R** x 4pcs




**S** x 2pcs




**U**




**U1** x 2pcs



**U3** x 2pcs



Connecting Plate




## STEP 14

With assistant carefully flip unit over.



**O** x 18pcs





**P** x 4pcs



**U**



**Q** x 2pcs





Peel off the adhesive sticker's protective paper and bond it onto the designated position before secure with nails.

## STEP 15

**R** x 4pcs   
5/6" nail

**S** x 2pcs 

**U** 



## STEP 16


- Move unit to final location.
- Adjust drawer fronts as shown below.

Step1--Loosen screws on back of drawer front brackets as shown.


Step2--Position drawer front as required.

Step3--Tighten screws while holding drawer front in position.


DRAWER FRONT VIEW




STEP 1.




STEP 2.




STEP 3.




With assistant carefully stand unit up.



STEP 1



STEP 2





An assistant is required.

## STEP 17


**U<sub>4</sub>** x 2pcs 

1. Place unit in desired location.
2. Mark stud location on the wall, 1" below top and side of unit.
3. Drill 5/16" hole 2" deep at marks on the wall.




# STEP 18

U<sub>1</sub> x2pcs



U<sub>3</sub> x2pcs



U<sub>5</sub> x2pcs

