

















Assembly Instruction

Number	Parts Identification		Q'ty
A		Headboard	1
B		Footboard	1
C		Side Rail	2
D		Middle Slat	1
E		Slat	1


Number	Hardware List		Q'ty
1		Long Screw	8
2		Nut	8
3		Hex key	1
4		Footboard & Side Rail Support	4
5		Adjustable support feet	4
6		Short Screw	40
7		Small Screw	8
8		L-shaped angle Bracket	4
9		U-shaped angle Bracket	2
5		Adjustable support feet	2

in
one
ctn.


Step1 :




a: Use the Long Screw (1) and Nut (2) to secure the Adjustable support feet (5) to the Footboard & Side Rail Support (4) with Hex key (3)




b: Use the Short Screw (6) to secure the Adjustable support feet (5) to the Middle Slat [D]



c: Use the Short Screw (6) to secure the U-shaped angle Bracket (9) to the Headboard [A] (Location as in Pic)




d: Use the Short Screw (6) to secure the U-shaped angle Bracket (9) to the Footboard (Location as in Pic)




e: Use the Short Screw (6) to secure the L-shaped angle Bracket (8) to the Side Rail [C] (Location as in Pic) Note that the long upper and lower adjustable slots in the L-shaped angle Bracket (8) are reserved for mounting Short Screw (6) to properly align the footboard and the [B] and the side rail [C]


Step2:



f: Secure the assembled Footboard \[B] to the Side Rail \[C] with Short Screw (6)




g: Secure the Footboard & Side Rail Support to the assembled footboard \[B] and side rails \[C] with Short Screw (6)




pay attention to the direction, the horizontally adjustable holes should be installed on the footer

Step3:

h: Secure the Side Rail \[C] and Headboard \[A] with Short Screw (6).



i: 1. Secure the Footboard & Side Rail Support ③ to the Headboard \[A] and side rails \[C] with Short Screw (6).
2. Put the assembled Middle Slat \[D] into the U-shaped angle Bracket (9) and lock it with 2 Small Screws (7)



Step4:

h: Secure the Slat \[F] (bandage secured) with Small Screws (7).

