
Using Camlocks


Step 1

Connect the male camlock as diected in the assembly instructions using a scewdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the femle camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.



Step 4


Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.


The joint is now secure.



Read each step carefully before starting. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.




Assembly Instructions



Components - Panels

Please check you have all the panels listed below



Hardware list

Please check you have all the panels listed below

Note: The quantities below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.

A	B	©
Male Camlock x 28+4	Female Camlock x 28+4	Dowel (8x30) x 28+4
D CONTRACTOR		
Door Hinge x 2	4*14mm Screw x 10+1	3*16mm Screw x 8+1
G		
Plasticwedge x 4	6*40mm Screw x 4	Shelf Support Pin x 4
1	K S	
Handle & Fixings x 1	Magnet Touch x 1	3*14mm Screw x 4
	0	O Spining
Ø20 Sticker x 24	Socket x1	3.5*14mm Screw x 2
P	0	R Q
Light Strip x 1	Wire Holder x 2	Glue Thread Clasp x 1

Tools required





Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

The screws length is measured from the head to the point (30mm screw shown).















































































































Assembly is complete.



Note: If the end table is not stable, please check that all screws are installed and tightened.